

GOODS INSTALLATION INSTRUCTIONS, RECOMMENDATIONS AND GENERAL TERMS AND CONDITIONS OF THE WARRANTY

INSTALLATION OF THE ALTERNATOR

1. Insert and screw lightly the alternator.
2. Put on and stretch the V-belt.
3. First tighten the clamping screw at the regulation yoke, then the front screw and the nut.
4. Put in the multi-contact plug and secure it with a clamp.
5. Connect the ground cable to the battery.

Proper connection of the alternator

- Disconnect the negative (-) battery cable in order to avoid short circuit during replacement.
- Control the condition of battery charging.
- Disconnect the alternator cables.
- Remove the alternator.
- Install the new alternator.
- Check the condition of the cable ends in terms of contamination, corrosion and the condition of the insulation.
- Connect the electric cables to the alternator.
- Connect the negative cable to the battery.

Installation and tension of the V-belt

1. Prior to installation check the V-belt.
2. Always replace the belt when it's shredded on the working surfaces or cracked.
3. Put on the V-belt.

Stretching

1. Pull away with the use of the tyre lever the V-belt.
2. Press the V-belt with the thumb between the pulley and in the middle of the longest section. The belt can bend maximally by 4 mm, the total clearance must be ca. 10 mm or the belt must be stretched.
3. Tighten the clamping screw of the regulation yoke and check the tension of the V-belt again.
4. First tighten the front and then the back screw fixing the alternator.

INSTALLATION OF THE STARTER

In order to install the starter it is necessary to perform the following activities:

1. Check if the cable ends are well fitted and if they are not corroded, potential signs of corrosion must be removed and the cables covered with small amount of fat, using the technical petrolatum.
2. Check the condition of teeth on the rim.
3. Tighten the starter to the engine block, remembering about the ground cable.
4. Screw the power supply cable from the battery (in some types from the alternator) to the electromagnetic switch.
5. Put the cables on the sleeve joints or screws.
6. Connect the ground cable to the battery (disconnection of the negative pole prevents short circuits at other works).
7. Check the condition of the battery.

NOTE:

Do not connect a cable with unknown polarization.

Connection can be checked by means of short approaching of the cable and concurrent start of the ignition switch and observation if the starter works.

WARRANTY SCOPE:

1. The warranty covers the physical defects of the Product resulting from the reasons in it.
2. The warranty covers only the Products which have been used according to their intended application.
3. The warrantor does not bear any liability for defects resulting from the improper use of the Product or its improper installation or its improper disassembly or improper use, including damage to or disassembly of protection, bands, seals, etc.
4. The warrantor does not bear any liability for defects resulting from any form of tampering with the Product structure.
5. The warrantor does not bear any liability for defects revealed in Products which have not been assembled or disassembled in the registered plants / car repair garages.
6. The warrantor does not bear any liability for defects if the Product has been used in conditions exceeding the admissible norms of use or overloading.
7. The warrantor does not bear any liability for defects resulting from the transport of the Product.
8. The warrantor does not bear any liability for defects of the Product resulting from the failure of the suspension system or other systems the Product cooperates with or which have influence on the functioning of the Product.
9. The warrantor does not bear any liability for the defects if the complaining party knew about the defect at the time of release of the Product to him/her.
10. The defect of the Product must be reported within the scope of the so-called complaint.
11. Accepting the complaint, the warrantor undertakes to:
 - remove the reported defect,
 - or replace the Product with the same one,
 - or with a Product with equal technical features or its part free from defects,

- or reimburse the payment for the Product in case of no possibility of replacement with the same Product or its part free from defects.

12. The complaint decision depends on the warrantor.

13. The time limit of the warranty is 25 months, however not more than to the mileage of 40,000 km and it runs from the day of purchase of the Product, at the place where the Warranty Card was issued. The condition of use of the warranty is possession of the purchase proof by the buyer in the form of a receipt or bill or VAT invoice and proper completion of the installation sheet in the enclosed form.

14. In other cases the time limit of the warranty is prolonged by the time where the complaining person could not use the Product due to the defect.

15. At the governance of the conditions provided for in the warranty card, the parties fully exclude the governance of guarantee.

Complaint report

1. The complaint is reported at the place of purchase of the Product where the Warranty Card was issued.

2. No duplicates of the Warranty Card are issued.

3. The complaint is reported on the form prepared by the warrantor and issued to the complaining person at the place of purchase of the Product.

4. The complaint form must include, in particular, the Product series number placed on its body, signature and stamp of the mechanic/workshop installing the Product.

5. A complaint which fails to fulfil the above requirements will not be reviewed.

6. The complaint must be reported immediately, however not later than within 7 calendar days from the statement of the defect.

7. At the report of the complaint the complaining person presents the Product, Warranty Card and original proof confirming the purchase of the Product.

Complaint review time

1. The warrantor reviews the complaint within 14 working days from the date of delivery of the Product to him.
2. In particularly justified cases, in particular when there is a need for specialised tests, prior to the lapse of the time limit specified above, the warrantor informs on the prolongation of the time limit for complaint review by another 14 working days.